

PowerLite 503c / 713c

<u>DESCRIPTION</u>	<u>PART NUMBER</u>
AC Power Cable	201 7328
A/V Cable (RCA Plugs)	600 2366
Computer Cable (VGA Cable)	202 2604
PS/2 Mouse Cable	600 2771
USB Mouse Cable	600 2770
Lamp (ELPLP14)	600 5199
Remote Control	600 2911
Lens Cap with String	600 2781
User's Manual	CPD-11727
Black, Soft Carrying Case (Portfolio style) (no shoulder strap)	754 4082

Order user replaceable parts from an [Epson authorized parts distributor](#).

---- OR ----

Locate an Epson Authorized Service Center to order user replaceable parts by using the "Help me find..." tool in the right column of the [Epson Support](#) home page.